



**Electrical Circuit Diagrams**  
**Elektrische Circuitdiagrammen**  
**Schémas électriques**  
**Elektrische Schaltpläne**  
**Schemi elettrici**  
**Esquemas de Circuitos Eléctricos**  
**Diagramas dos Circuitos Eléctricos**



# CONTENTS

|   |  |   |
|---|--|---|
| <b>POWER DISTRIBUTION</b>                 | <b>ENGINE MANAGEMENT</b>   | <b>EXTERIOR LAMPS</b>                               |
| Engine Compartment Fuse Box ..... 1.1     | Td5..... 20.1  | Brake and Reverse Lamps ..... 43.1                  |
| Passenger Compartment Fuse Box..... 1.4   | V8 ..... 20.4  | Headlamp Levelling ..... 43.2                       |
| <b>EARTH DISTRIBUTION ..... 2.1</b>       | <b>IGNITION/SHIFT INTERLOCK ..... 25.1</b>                           | Lights On Alarm ..... 43.3                          |
| <b>ANTI-THEFT ALARM ..... 3.1</b>         | <b>CRUISE CONTROL..... 31.1</b>                                      | Head, Side and Tail Lamps ..... 43.4                |
| <b>CENTRAL DOOR LOCKING ..... 4.1</b>     | <b>ELECTRONIC AUTOMATIC TRANSMISSION (EAT) ..... 32.1</b>            | Front Fog Lamps ..... 43.6                          |
| <b>WINDOWS</b>                            | <b>ACTIVE CORNERING ENHANCEMENT (ACE)..... 33.1</b>                  | Rear Fog Guard Lamps..... 43.7                      |
| Front ..... 5.1                           | <b>SELF LEVELING AND ANTI-LOCK BRAKING SYSTEM (SLABS) ..... 34.1</b> | Direction Indicator/Hazard Warning Lamps ..... 43.8 |
| Rear ..... 5.2                            | <b>ANTI-LOCK BRAKING SYSTEM (ABS) ..... 35.1</b>                     | <b>INTERIOR LAMPS ..... 44.1</b>                    |
| <b>SUNROOF ..... 6.1</b>                  | <b>SUPPLEMENTARY RESTRAINT SYSTEM (SRS)..... 36.1</b>                | <b>INTERIOR ILLUMINATION ..... 46.1</b>             |
| <b>DOOR MIRRORS ..... 7.1</b>             | <b>AIR CONDITIONING (A/C) ..... 38.1</b>                             | <b>INSTRUMENTS ..... 47.1</b>                       |
| <b>FOLDING DOOR MIRRORS ..... 7.3</b>     | <b>HEATER BLOWER ..... 38.5</b>                                      | <b>HORNS ..... 48.1</b>                             |
| <b>SEATS</b>                              | <b>FUEL BURNING HEATER (FBH) ..... 39.1</b>                          | <b>CLOCK ..... 48.2</b>                             |
| Power - Heated ..... 8.1                  | <b>COOLING FANS ..... 39.2</b>                                       | <b>CIGAR LIGHTER ..... 49.1</b>                     |
| Manual - Heated..... 8.4                  | <b>HEATED REAR WINDOW (HRW) ..... 40.1</b>                           | <b>ACCESSORY SOCKET ..... 49.2</b>                  |
| <b>DIAGNOSTIC SOCKET..... 10.1</b>        | <b>HEATED FRONT SCREEN..... 40.2</b>                                 | <b>AUDIO SYSTEMS</b>                                |
| <b>BODY CONTROL UNIT (BCU) ..... 11.1</b> | <b>WIPERS AND WASHERS</b>  | Base and Mid Line ..... 50.1                        |
| <b>CHARGING AND STARTING</b>              | Front ..... 42.1   | High Line - Harman Amplifier ..... 50.3             |
| Td5..... 15.1                             | Rear ..... 42.2  | High Line - Lear Amplifier ..... 50.7               |
| V8 ..... 15.2                             |  | <b>HEADER JOINTS..... 60.1</b>                      |
|   |  | <b>SPLICES AND CENTRE TAPS ..... 65.1</b>           |


# HOW TO USE THE CIRCUIT DIAGRAMS

All of the information in this folder is intended for use with the Electrical Reference Library booklet.

The circuit diagrams are presented with Power and Earth distribution first, followed by individual circuits for each electrical system on the car.

## Power Distribution

The Power Distribution diagram shows the connections from the battery to the engine and passenger compartment fuseboxes. It also shows the internal circuitry of the fuseboxes.



These fuse box details are followed by a Headers and Splices section outlining the way in which internal harness splices and header joints distribute power in the harnesses. This information should be used during diagnosis of electrical faults to check for symptoms in associated circuits and narrow down the search area.

## Headers and splices

Header and splice tables present the joint(s) and wiring up to the first component. Splices are identified by a number with an alphabetical prefix and the wire colour.

**The splice information shown on individual system circuits is not complete. Always refer to the splices circuit for complete information on each splice.**

## Wire attributes

Additional information (separated by a ',') is shown alongside the wire colour:  
Wire gauge - the cross-sectional area of the wire in square millimetres. This is included to help you select the correct wire during harness repair.

Some wires do not have a gauge shown, these wires are of unique construction and will have a three or four letter code printed after the colour code, eg MAB. The code identifies the type of wire for manufacturing purposes. Usually, only the first two characters have significance in service, but in some instances the third character also becomes significant, see Wire Type information given below.

## Wire type

The following table lists the wire type codes together with an explanation of their meaning.

| Code | Description                                    |
|------|--|
| MAB  | Twin core screened wire                        |
| MAH  | Coaxial screened wire                          |
| MAT  | Twin core double sheath                        |
| MCA  | Twisted core screened wire                     |
| MD*  | Twisted core ABS sensor wire                   |
| ME*  | Twisted pair of wires min. 33 twists per metre |
| MM*  | Twisted pair of wires                          |
| MQ*  | Twin core foil screened cable                  |
| MZ*  | Three core screened flexible cable             |


Wire length (Power & Earth Distribution only) - the length of the wire in millimetres. This can be used to locate internal harness splices; look for the shortest wire between the joint and connector. For example, it can be seen that C574-4 is 150mm from joint A82.

## Earth Distribution

The ground distribution section comprises a number of Headers and Splices tables. These are used in a similar manner to those in Power Distribution; to narrow the search area by checking for fault symptoms in associated circuits.

## Connectors

HEADER JOINT (K109)



86M4228A

HEADER JOINT 289

Header joints are identified by their corresponding connector number with a numbered suffix to indicate the pin-out detail of the wire, i.e. C289-1 identifies connector 289, pin number 1. Wire insulation colour is identified in the normal way. Where wires have a predominant colour with a secondary colour stripe, the main colour is identified first, i.e. LGS - Light Green with a Slate stripe.

## HOW TO USE THE CIRCUIT DIAGRAMS

---


### Line Types




86M4229A

This means the wire connects to another circuit.

A



B




86M4230A

The cup and ball symbol indicates the male and female halves of connector.

A. Plug on lead (Flylead) wired directly to the component.

B. Connector plugs directly into component.


### Components



86M4231A

The name or description of the component is shown. A dotted outline indicates that the component is not shown in its entirety.



### Earth points




86M4232A

Earth points are identified with an eyelet symbol and a connector number, except where components are grounded through their fixings, when only the eyelet is shown.


### Fuses and Diodes



C



D



86M4234A


Fusible links (A) and current rated fuses (B) are identified as shown.

The direction of the arrow in a Diode symbol (C) indicates the direction of current flow. The Zener diode (D) - prevents current flow until a precise voltage is reached.

# POWER DISTRIBUTION

## ENGINE COMPARTMENT FUSEBOX


FUSE BOX-ENGINE COMPARTMENT (P108)



VWR108520-1of6

# POWER DISTRIBUTION


## ENGINE COMPARTMENT FUSEBOX



VWR108520-2of6

# POWER DISTRIBUTION

## ENGINE COMPARTMENT FUSEBOX




VWR108520-3of6




# POWER DISTRIBUTION

## PASSENGER COMPARTMENT FUSEBOX




VWR108520-406

## **POWER DISTRIBUTION PASSENGER COMPARTMENT FUSEBOX**



# POWER DISTRIBUTION


## PASSENGER COMPARTMENT FUSEBOX




WWR108520-6of6



## EARTH DISTRIBUTION




# EARTH DISTRIBUTION




VWR108260-2of7


# EARTH DISTRIBUTION




## EARTH DISTRIBUTION



## EARTH DISTRIBUTION




# EARTH DISTRIBUTION




VWR108260-707

## ANTI-THEFT ALARM




VWR108140-1of4

## ANTI-THEFT ALARM




## ANTI-THEFT ALARM




VWR108140-3of4

## ANTI-THEFT ALARM




## CENTRAL DOOR LOCKING




VWR108170-1of3

# CENTRAL DOOR LOCKING



# CENTRAL DOOR LOCKING




VWR108170-3of3




# WINDOWS FRONT

---




VWR108610-1of1

## WINDOWS REAR




VWR108640-1of1

# SUNROOF






## DOOR MIRRORS




VWR108510-1of2

## DOOR MIRRORS




## FOLDING DOOR MIRRORS






# SEATS

## POWER - HEATED



# SEATS


## POWER - HEATED



VWR108530-2of3

# SEATS


## POWER - HEATED



VWR108530-3of3


# SEATS

## MANUAL - HEATED




VWR111060-1of1

## **DIAGNOSTIC SOCKET**






# BODY CONTROL UNIT (BCU)




VWR108210-1of3

# BODY CONTROL UNIT (BCU)



VWR108210-2of3


## BODY CONTROL UNIT (BCU)





## **CHARGING AND STARTING**


Td5



VWR108570-1of1

# CHARGING AND STARTING


V8



VWR108580-1of1

# ENGINE MANAGEMENT


Td5



VWR108270-1of3

# ENGINE MANAGEMENT


Td5



VWR108270-2of3

# ENGINE MANAGEMENT

Td5




VWR108270-3of3




## **ENGINE MANAGEMENT**

V8




# ENGINE MANAGEMENT

V8




# ENGINE MANAGEMENT


V8



## **IGNITION/SHIFT INTERLOCK**




# CRUISE CONTROL






## ELECTRONIC AUTOMATIC TRANSMISSION (EAT)




VWR108600-1of2

## ELECTRONIC AUTOMATIC TRANSMISSION (EAT)




VWR108600-2of2

## ACTIVE CORNERING ENHANCEMENT (ACE)




## ACTIVE CORNERING ENHANCEMENT (ACE)




VWR108150-2of2

## SELF LEVELLING AND ANTI-LOCK BRAKING SYSTEM (SLABS)




## SELF LEVELLING AND ANTI-LOCK BRAKING SYSTEM (SLABS)




VWR108540-2of4

## **SELF LEVELLING AND ANTI-LOCK BRAKING SYSTEM (SLABS)**




## SELF LEVELLING AND ANTI-LOCK BRAKING SYSTEM (SLABS)




VWR108540-4of4

## ANTI-LOCK BRAKING SYSTEM (ABS)




VWR108100-1of3

## ANTI-LOCK BRAKING SYSTEM (ABS)




VWR108100-2of3


# ANTI-LOCK BRAKING SYSTEM (ABS)



VWR108100-3of3




## AIR CONDITIONING (A/C)




VWR108130-1of4

## AIR CONDITIONING (A/C)




VWR108130-2of4

# AIR CONDITIONING (A/C)




VWR108130-3of4

## AIR CONDITIONING (A/C)




VWR108130-40f4

## HEATER BLOWER




## FUEL BURNING HEATER (FBH)




## COOLING FANS

---






## HEATED REAR WINDOW (HRW)




VWR108390-1of1

## **HEATED FRONT SCREEN**




# WIPERS AND WASHERS FRONT




VWR108650-1of1

# WIPERS AND WASHERS REAR




# **EXTERIOR LAMPS**

## **BRAKE AND REVERSE LAMPS**



## EXTERIOR LAMPS


### HEADLAMP LEVELLING



VWR108370-1of1

# EXTERIOR LAMPS


## LIGHTS ON ALARM






# EXTERIOR LAMPS

## HEAD, SIDE AND TAIL LAMPS




# EXTERIOR LAMPS

## HEAD, SIDE AND TAIL LAMPS




## **EXTERIOR LAMPS**

### **FRONT FOG LAMPS**



## EXTERIOR LAMPS


### REAR FOG GUARD LAMPS



VWR108300-1of1

# EXTERIOR LAMPS


## DIRECTION INDICATOR/HAZARD WARNING LAMPS




VWR108460-1of1



## INTERIOR LAMPS




## INTERIOR LAMPS




VWR108490-2of2

## INTERIOR ILLUMINATION




VWR108480-1of2

## INTERIOR ILLUMINATION




VWR108480-2of2

# INSTRUMENTS




VWR108470-1of3

# INSTRUMENTS




# INSTRUMENTS




## HORNS

---




# CLOCK




VWR108200-1of1

## CIGAR LIGHTER




## ACCESSORY SOCKET




VWR108120-1of2

## ACCESSORY SOCKET

---




# AUDIO SYSTEMS BASE AND MID LINE



VWR108420-1of2

# AUDIO SYSTEMS


## BASE AND MID LINE



VWR108420-2of2

# AUDIO SYSTEMS


## HIGH-LINE - HARMAN AMPLIFIER



VWR108440-1of4

# AUDIO SYSTEMS


## HIGH LINE - HARMAN AMPLIFIER



VWR108440-2of3


# AUDIO SYSTEMS

## HIGH LINE - HARMAN AMPLIFIER




# **AUDIO SYSTEMS**

## **HIGH-LINE - HARMAN AMPLIFIER**



## AUDIO SYSTEMS


## HIGH LINE - LEAR AMPLIFIER



VWR001480-A-01

# AUDIO SYSTEMS


## HIGH LINE - LEAR AMPLIFIER



VWR001480-A-02

# AUDIO SYSTEMS


## HIGH LINE - LEAR AMPLIFIER




VWR001480-A-03

# AUDIO SYSTEMS

## HIGH LINE - LEAR AMPLIFIER





## HEADER JOINTS




VWR108360-1df9


# HEADER JOINTS




# HEADER JOINTS



# HEADER JOINTS



# HEADER JOINTS




VWR108360-5of9

## HEADER JOINTS




## HEADER JOINTS



VWR108360-7of9

## **HEADER JOINTS**




# HEADER JOINTS

---






## SPLICES AND CENTRE TAPS




VWR108550-1of5


## SPLICES AND CENTRE TAPS



## SPLICES AND CENTRE TAPS




## SPLICES AND CENTRE TAPS



VWR108550-405

## SPLICES AND CENTRE TAPS



VWR108550-5of5